BS ISO 23139:2023



Biological equipment for treating air and other gases — Requirements and application guidance for deodorization in wastewater treatment plants



National foreword

This British Standard is the UK implementation of <u>ISO 23139:2023</u> The UK participation in its preparation was entrusted to **TG** nical Committee MCE/21, Filters for gases and liquids.

6m A list of organizations represented on this of ttee can be obtained on request to its committee manager.

Contractual and legal considerations

This publication has been prepared in good faith, however no representation, warranty, assurance or undertaking (express or implied) Sr will be made, and no responsibility or liability is or will be recepted by BSI in relation to the adequacy, accuracy, completeness or reasonableness of this publication. All and any such responsibility and liability is expressly disclaimed to the full extent permitted by the law.

This publication is provided as is, and is to be used at the recipient's own risk.

The recipient is advised to consider seeking professional guidance with respect to its use of this publication.

This publication is not intended to constitute a contract. Users are responsible for its correct application.

© The British Standards Institution 2023 Published by BSI Standards Limited 2023

ISBN 978 0 539 15615 7

ICS 91.140.30

Compliance with a British Standard cannot confer immunity from legal obligations.

This British Standard was published under the authority of the Standards Policy and Strategy Committee on 31 August 2023.

Amendments/corrigenda issued since publication

Text affected Date

INTERNATIONAL STANDARD

ISO 23139

WWW.MWWMWWMWWModelMultiple<t



Reference number ISO 23139:2023(E) https://www.china-gauges.com/



© ISO 2023, Published in Switzerland

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office Ch. de Blandonnet 8 • CP 401 CH-1214 Vernier, Geneva, Switzerland Tel. +41 22 749 01 11 Fax +41 22 749 09 47 copyright@iso.org www.iso.org

Page

Contents

Fore	reword	<u>n</u> liv
Intro	roduction	CO1.
1	Scope	
2	Normative references	1
3	Terms and definitions	
4	Odour gas characterization and process design4.1Odour gas characterization4.2Process design	
5	Requirement for manufacture, installation and operation5.1Manufacture are installation5.2Start-up5.3Operation and maintenance	
6	Performance assessment6.1Measurement of some specific indexes for odour gas6.1.1Flow rate, temperature and relative humidity of the odour gas6.1.2Pressure drop of the filter bed6.1.3Concentration of odorants6.1.4Odour concentration6.2Calculation of odorant removal efficiency6.3Calculation of odorant removal rate	7 7 57 8 8 8 8 8 8 8 8 8 8 8 8
7	Safety and secondary pollution control7.1Safety control7.2Secondary pollution control	9 9 9
Bibl	oliography	

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standard bodies (ISO member bodies). The work of preparing International Standards is normally carried on through ISO technical committees. Each member body interested in a subject for which Ctechnical committee has been established has the right to be represented on that committee Dternational organizations, governmental and non-governmental, in liaison with ISO, also take back in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those interded for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, we different approval criteria needed for the different types of ISO document should be noted. Note document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

ISO draws attention to the possibility at the implementation of this document may involve the use of (a) patent(s). ISO takes no position concerning the evidence, validity or applicability of any claimed patent rights in respect thereof. As of the date of publication of this document, ISO had not received notice of (a) patent(s) which may be required to implement this document. However, implementers are cautioned that this may not represent the latest information, which may be obtained from the patent database available at www.iso.org/patents. ISO shall not be held responsible for identifying any or all such patent rights.

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT), see <u>www.iso.</u> org/iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 142, *Cleaning equipment for air and other gases.*

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at <u>www.iso.org/members.html</u>.

Introduction

There are tens of thousands of wastewater treatment plants (WWTPs) running worldwide post of which produce odour gas as secondary pollution. The typical contaminants in odour an include hydrogen sulfide, ammonia and volatile organic compounds (VOCs). Besides, hydrogen sulfide in odour gas can also lead to severe corrosion on structure and pipeline and treases the risk of accidental poisoning.

Among different techniques, biological techniques have been reconnized as a cost-effective and most applied method for WWTPs deodorization. Biological methods the odour gases through microbial metabolism. Their advantages are low operational cost, simple to operate, very safe to use and having lower secondary pollution levels. The typical biological equipment includes biofilter, biotrickling filter and bioscrubber. The biological techniques were used for about 70 years to effectively treat the odour gas emitted from WWTPs. A great amount of experience has been gathered on biological equipment from work carried out on numerical sites around the world. However, the biological odour gas treatment facilities varied greatly from case to case, both in configuration and performance.

Therefore, it is necessary to develop a standard at the international level by collating the successful experiences together and providing a guidance for the installation and application of biological odour treatment equipment worldwide.

https://www.china-gauges.com/

ISO 23139:2023

Biological equipment for treating air and other gases

Requirements and application guidance for deodorization in wastewater treatment plants 1 Scope This document specifies the requirements and application guidance for biological deodorization systems in wastewater treatment plants (WMTPs). The specific requirements include odour gas characterization, process selection equipment manufacture and installation, start-up and operation, performance evaluation, security and secondary pollution control.

The guidance can help the development and maintenance of biological deodorization systems in WWTPs and benefits the owners and operators of WWTPs.

2 Normative references

There are no normative references in this document.

Terms and definitions 3

For the purposes of this document, the following terms and definitions apply.

ISO and IEC maintain terminology databases for use in standardization at the following addresses:

ISO Online browsing platform: available at https://www.iso.org/obp

- IEC Electropedia: available at http://www.electropedia.org/

3.1

wastewater treatment plant WWTP

plant that purifies wastewater with physical, chemical, biological methods or a combination of those to make the discharge conform to the requirements of discharge standards or the need for environmental protection

3.2

odorant

substance which has the potential to get volatilized and stimulate a human olfactory system so that an odour is perceived

Note 1 to entry: Typical odorants in WWTPs include sulfur-containing compounds (hydrogen sulfide, organic sulfides), nitrogen-containing compounds (ammonia, amines) and volatile organic compounds (VOCs).

3.3

odour gas

waste gas containing odorants emitted from industrial, civil or domestic processes

3.4

odour source in WWTPs

structure or equipment emitting odour gases in a wastewater treatment plant

Note 1 to entry: In WWTPs, the primary odour source includes the wastewater pre-treatment units, an explore treatment units and waste sludge treatment units. Sulfides including hydrogen sulfide are the typical odor ants from the raw wastewater. Sulfides, ammonia and VOCs are the typical odorants from the raw estimate. The emission increases where there is turbulence or disturb in the wastewater or waste sludge. The emission increases where there is turbulence or disturb in the stewater or waste sludge. The additional end of the odour of odour intensity through tests with olf for y organs. Note 1 to entry: The value of odour concentration is the sluted multiples of the odour are served.

is the duted multiples of the odour gas samples to the detection threshold value of panellists using clean a

Note 2 to entry: The odour concentration (1) aw odour gas varies greatly from case to case and is affected by odorants emission rate and configuration of collection system. Odour concentration can be measured according to different methodologies such as ASTM D 1391, EN 13725 or GB/T 14675-93.

Note 3 to entry: The odour concentrations measured by different methods cannot be compared directly.

3.6

bioreactor for deodorization

biological reactors used to treat odour gases collected from different odour sources to minimize the emission of odorants

Note 1 to entry: Biological reactors for waste gas treatment are typically biofilm reactors with microbial colonies immobilized on the surface of packing media, such as a biofilter or a trickling biofilter. The other type of biological reactors are suspended-growth reactors with the microbial populations suspended in a liquid medium, such as a bioscrubber. For WWTPs applications, biofilters and trickling biofilters are much more applied than bioscrubbers.

3.7

biofilter

bioreactor treating waste gas with the aid of biofilm attached to the packing media which moisture is maintained by a prepositive humidifier or intermittent water feeding to the filter bed

Note 1 to entry: The typical packing media employed are organic or/and inert materials randomly packed in the filter beds.

3.8

trickling biofilter biotrickling filter

bioreactor treating waste gas with free moving liquid layers on the surface of inert packing media to supply nutrients, take away metabolites or control pH for the biofilm attached to the packing media

Note 1 to entry: The typical packing media employed are inert materials randomly or structured packed in the filter beds.

Note 2 to entry: External nutrients addition is required when the packing media cannot offer enough nutrients for the growth of microorganism.

3.9

bioscrubber

absorber transferring contaminants from waste gas to liquid absorbent, and removing the dissolved contaminants by suspended-growth microorganisms in a supplementary space

Note 1 to entry: The built-in device of the scrubbing unit can be a bulk or structured packing or a construction with plates or a rotating disk.

Note 2 to entry: External nutrients addition is usually required.

Note 3 to entry: Pre-humidification is not required.

3.10

bed including the packing media and the microorganisms on the surface of packing media

at a state and only or Note 1 to entry: The typical packing media employed are natural or/and arti structured packed.

Note 2 to entry: The typical microorganisms are bacteria or/and fungion of packing media or free cells in the liquid. biofilm on the surface of the

Note 3 to entry: Odour gas passes through the filter had and degradation of odorants. **3.11 superficial velocity** volumetric odour gas flow the divided by the free crosses gets purified by mass transfer and biological

volumetric odour gas flov vided by the free cross-section area of the bioreactor column, with unit in m/s or m/h

3.12 empty bed residence time **EBRT**

total volume of the filter bed divided by the odour gas flow rate

Note 1 to entry: Unit is in s.

3.13 odorant removal efficiency E

ratio of odorant concentration reduction and inlet odorant concentration

Note 1 to entry: Removal efficiency is also referred to as elimination efficiency.

3.14 odorant removal rate r

amount of odorants removed by a unit volume of packing material in a unit time

Note 1 to entry: Removal rate (r) is also referred to as elimination capacity (EC) or elimination rate (ER).

Note 2 to entry: It is generally used to evaluate the capacity of the reactors for odorant removal. It is very relevant and useful for the comparison of various bioreactors. It is important to note that E is dependent upon the inlet odorant concentration or EBRT of a bioreactor.

Note 3 to entry: The maximum removal rate is the maximum value of instantaneous elimination capacities in

 $g/(m^3 \cdot h)$ while increasing the inlet loading.

3.15

pressure drop

difference in static gas pressure between the inlet and outlet of the equipment

Note 1 to entry: The pressure drop of the bioreactor and odour gas collection duct will affect the energy consumption of the blower and its operational costs. The pressure drop of the bioreactor is mainly decided by the character of the filter bed and the superficial velocity.

Odour gas characterization and process design 4

Odour gas characterization 4.1

The main odour sources in WWTPs are covered and the odour gases emitted from different s predominantly are collected by a pipeline system. The bioreactor for deodorization installed at l of the pipeline system and treats the total mixture of odour gases. In some and with small of ut high odour concentrations, a separate treatment with 4.1.1 sources predominantly are collected by a pipeline system. The bioreactor for deodorization the end of the pipeline system and treats the total mixture of odour gases. In some pipeline, with the odour concentrations a separate treatment unit for this source on be useful.

The characteristics of the odour gas include the flow 4.1.2 the odorants component and concentration in the odour gas, emission rate of odorants he temperature and the relative humidity etc. The characteristics of the odour gas affect the design and operation of the odour gas collection and treatment system. An adequate and precise characterization on odour gas helps to achieve better performance and less cost.

4.1.3 When the odour gas collection pipeline system is installed, the characteristics of odour gas can be measured on-site at specific points of the pipeline system.

4.1.4 When there is no gas collection pipeline system, the emission rates (in $g/(m^2 \cdot h)$) of odorants can be measured by using a flux chamber or wind tunnel on the surface of wastewater (referring to EN 13725 for example). For WWTPs not installed yet, the references on previous similar applications are also needed.

4.2 Process design

4.2.1 The biological deodorization process can include some pre-treatment units and a biological reactor in series as illustrated in Figure 1.



Figure 1 — Scheme of a biological deodorization equipment

Key

1 2

3

4

5

6

4.2.2 Pre-treatment units can be a filter to remove the particulates or a humidifier to increase the relative humidity of odour gas. If the hydrogen sulfide or ammonia concentrations in odour gas are too high to inhibit the microorganisms in the bioreactors, a scrubbers or absorbers as a pre-treatment can also be considered.

4.2.3 The biological reactor is usually a biofilter or a trickling biofilter which the tack des the reactor column, filter bed and the water feeding system. The water feeding system should include pumps, spray nozzles, pipelines and the water tank. Some chemical or biological agents such as nutrients, pH regulator or inocula can be added in the water tank and sprayed into the filter reaction he leachate can be recycled to water tank or be discharged directly.

4.2.4 When a stand-alone bioreactor cannot meet the requirements for odour gas emission, other additional units, such as a biological stage, whemical scrubber or an activated carbon adsorber can be installed before or after the bioreactor.

4.2.5 The bioreactors for deodorization include biofilter, trickling biofilter and bioscrubber. Biofilters and trickling biofilters are in widespread use in WWTPs.

4.2.6 The common ranges of the design criteria for biofilters, trickling biofilters and bioscrubbers treating odour gases in WWTPs are shown in <u>Table 1</u>.

Design criteria	Biofilter	Trickling biofilter	Bioscrubber
EBRT (s)	≥20	≥10	≥2
Superficial velocity (m/s)	0,03 to 0,20	0,05 to 0,5	0,5 to 1,5
Superficial velocity (m/h)	100 to 700	200 to 2 000	1 500 to 5 000
Filter bed height (m)	0,5 to 3,0	2,0 to 5,0	-
Pressure drop (Pa/m)	≤200	≤300	_

Table 1 — Design criteria of the different bioreactors for odour control in WWTPs

4.2.7 The blower can be set before or after the bioreactor for deodorization and results in a positive or negative pressure in the bioreactor. Negative-pressure bioreactors with blower after is more applied and should avoid that the negative pressure is too low.

5 Requirement for manufacture, installation and operation

5.1 Manufacture and installation

5.1.1 The design and manufacture of the various structural parts of the reactor shall take into account the requirements on strength, rigidity, fire-proof and leakage-free. The service lifetime of the reactor structure shall be at least 20 years.

NOTE The loads imposed by filter bed are induced by the weights of packing media, moisture in the packing media, the biomass accumulated, and even the flooded water.

5.1.2 Due to the low pH environment induced by oxidation of hydrogen sulfide and volatile sulfur organics, all parts of the bioreactor, the pipes and the blower (if located after the bioreactor) shall be made of corrosion-resistant materials or have special anti-corrosion treatment to adapt to the corrosive and humid environment in the WWTPs.

NOTE In WWTPs, the used materials include fibre-reinforced plastics (FRP), polypropylene (PP), high-density polyethylene (HDPE), polyvinyl chloride (PVC) and 316L stainless steel.

5.1.3 The packing media shall meet the following requirements:

BS ISO 23139:2023 ISO 23139:2023

sufficient surface area and hydrophilic surface for biofilm attachment; a)

water holding capacity to allow microbial development and avoid frequent spray or bed drying; b)

- C)
- d)
- e)
- f)

E The commonly used packing media include wood, bark, sei, common The commonly used packing media include wood, bark, sei, common The packing the sease of the NOTE The commonly used packing media include wood, bark, soil, compost, peat, porous perlite, granular activated carbon, limestone, seashells, lava rock, grave soig, biochar, ceramics, PU foam and different plastic materials.
5.1.4 Packing media shall be evenly the filter bed with no gaps.

The set-up of a liquid distribution system inside the bioreactor shall produce a uniform water 5.1.5 irrigation on the top of the reactor bed.

5.1.6 After installation, the bioreactor for deodorization shall pass the performance test and meet the following requirements:

- leak inspection shall be carried out and gas leakage for the bioreactor shall be strictly controlled to a be less than 5 % for negative pressure installations;
- pipes and joints shall be guaranteed not to crack under 1,5 times the working pressure (vacuum); b)
- the flowrate of odour gas collected shall be within 80 % to 120 % of its designed level; c)
- the pressure drop of a clean filter bed with a spray shall be less than 200 Pa/m; d)
- the amount of spray per unit time shall meet the requirements to maintain no leakage in the e) pipeline and no clogging in the spray nozzle, and its uniformity shall be considered;
- the on-off valve and the meter shall work well and indicate correctly. f)

5.2 Start-up

Microbial inoculants with high biodegradation performance are needed for inoculation. Activated 5.2.1 sludge from the aeration tank or secondary sedimentation tank of the WWTP can be used for inoculation or microbes specifically cultured in a laboratory targeting specific compounds.

5.2.2 Microbial inoculants should be added in the leachate recycling tank directly. A recirculation can be applied without odour gas feeding for 1 min to 10 min, based on the packing characteristics, to spread the inoculants into the filter bed.

5.2.3 During the start-up period, the flowrate of the odour gas can be gradually increased from 20 % to 100 % of the full load in 2 to 10 days, which is beneficial to facilitate the rapid formation of biofilm on the surface of the packing media.

5.2.4 The intensity of the spray shall be controlled to avoid washing away the biofilm or flooding the filter bed.

5.2.5 Relatively stable removal for odorants like hydrogen sulfide or decrease in pH of leachate in combination with increasing levels of sulfate can indicate the successful formation of biofilm and startup of the bioreactor. Conversely, poor odorants removal or a decrease in pH of leachate without sulfate production indicates an unsuccessful start-up and a poor biofilm formation.

5.3 Operation and maintenance

The suitable temperature range of inlet odour gas is approximately office to 40 °C. Sor rature control measurements will need to be applied if odour gas approximately office to 40 °C. Sor If the inlet odour gas temperature is below 10 °C it could be applied if odour gas approximately of the odour d o 40 °C. Some 5.3.1 temperature control measurements will need to be applied if odour gas temperature is outside this range. If the inlet odour gas temperature is below 10 °C, it can be useful to reduce the flow rate through the bioreactor to lower the odour load and the heat loss.

5.3.2 Some condensed water drainage ports shall be set at the bottom wall of inlet or outlet pipelines and shall be opened periodically to discharge in condensed water.

5.3.3 For WWTP, the treated entrept water can be used as the sprayed nutrient solution if the water quality meets the following, 15-10 mg/l, COD<100 mg/l, NH₄-N<30 mg/l, pH 6 to 9 and there is no obvious inhibition of the microorganism.

5.3.4 Intermittent spray of nutrient solution by approximately 2 to 48 times per day can be applied on trickling biofilter. The optimal range for spray rate is $0,1 \text{ m}^3/(\text{m}^2 \cdot h)$ to $1 \text{ m}^3/(\text{m}^2 \cdot h)$. The amount of spray on the filter bed should be strictly controlled.

5.3.5 For biofilter or trickling biofilter treating sulfur-containing compounds only, the leachate pH can be controlled within approximately 2 to 7 or even lower. For those treating ammonia and VOCs, the leachate pH should be within 6 to 9. The conductivity of leachate should be determined for each specific application with reference to the leachate compositions, which is normally less than 1 000 ms/m.

5.3.6 The nozzles shall be checked regularly for any signs of clogging and these should be cleaned or replaced before they become clogged.

5.3.7 The filter bed and the packing media shall be monitored on a regular basis. Packing media shall be washed or partly replaced when abnormal pressure drops, internal collapse, packing media consolidation or breakage occur.

5.3.8 When using online monitoring instruments, the sensors shall be calibrated according to the manufacturer's recommendations and checked at least every six months during the effective service life to ensure accurate and effective gas monitoring. Sensors that have exceeded their validity period and have failed shall be replaced.

5.3.9 If a bioreactor is not operated for a long period (more than 1 week for example), problems such as microbial activity reduction can occur. There shall be a requirement for resuming inoculation and start-up operation.

Performance assessment 6

6.1 Measurement of some specific indexes for odour gas

6.1.1 Flow rate, temperature and relative humidity of the odour gas

At the specific sampling point in upstream or downstream duct of the bioreactor, the flow rate shall be measured by a portable anemometer (with a relative maximum permissible error less than ± 10 %) and the gas temperature and humidity shall be measured by a digital hygrometer (with maximum permissible error less than ±0,5 °C for temperature and ±3 % for relative humidity). The measurements for each index shall be repeated three times and an average result shall be calculated.

Pressure drop of the filter bed 6.1.2

The static pressure of odour gas in the duct can be measured by a portable pressure meter or a tube

manometer. The difference between the static pressures of the two sampling points (one measuring point shall be located before the bioreactor and another measuring point shall be located after the bioreactor) represents the pressure drop of relative facility.
6.1.3 Concentration of odorants
The concentrations of hydrogen sulfide, ammonia or VOC in the odayr por at the inlet or outlet of the bioreactor can be measured by some portable device with specific sensors (with a relative maximum permissible error less than ±5 %). The sampling port with the galaxies pressure inside the pipe should be sealed to prevent ambient air sucked in when the sensity probe is set into the port. The measurements for each index shall be repeated three times and an average result shall be calculated. The odorants can also be measured by using a sampling backer dampling solution and a subsequent detection based on also be measured by using a sampling baser sampling solution and a subsequent detection based on the colorimetric method or the chronia ography method. Sampling methods and subsequent analysis should be specially considered in case of condensing conditions.

Odour concentration 6.1.4

The odour gas at the inlet or outlet of bioreactor can be sampled and its odour concentration can be detected by trained professionals using an olfactometry or odour sampling bags. The specific procedure and requirements shall follow the relevant national and local standards or technical guidance.

6.2 Calculation of odorant removal efficiency

The performance of bioreactor for deodorization in WWTPs can be assessed in terms of odorant removal efficiency (E). If the composition of raw odour gas is complex, the main odorants shall be identified before their removal efficiencies are determined. The calculation method of odorant removal efficiency can be referred to as follows:

$$E = \left(1 - \frac{C_{\text{out}}}{C_{\text{in}}}\right) \times 100 \%$$

where

Ε is the removal efficiency (%);

is the inlet odorant concentration (mg/m^3) ; $C_{\rm in}$

is the outlet odorant concentration (mg/m^3) . Cout

6.3 Calculation of odorant removal rate

The odorant removal rate (r) provides a reliable basis for assessing the removal performance of the bioreactor by the following formula:

$$r = \frac{(C_{\rm in} - C_{\rm out}) \times Q}{V} \times 10^{-3}$$

where

is the odorant removal rate $[g/(m^3 \cdot h)]$; r

is the inlet odorant concentration (mg/m^3) ; C_{in}

is the outlet odorant concentration (mg/m^3) ; Cout

- is the volumetric flow rate (m^3/h) ; Q
- V is the volume of filter bed (m^3) .

Safety and secondary pollution control 7

7.1.1 For WWTPs which have sludge fermentation or methane storage units, the tigh concentrated hydrogen sulfide or ammonia can cause poisoning, while high concentrated wethane can cause explosion risks.
7.1.2 Odour gas leakage should be strictly controlled induction for the deodorization system installed indoors.
7.1.3 The deodorization system shall be strictly before overhauling. The internal gas shall be removed first, and fresh air shall be introduced. Natural ventilation or forced ventilation can be adopted.
7.1.4 Before the staff enter the equipment for matin.

7.1.4 Before the staff enter the equipment for maintenance, a monitoring of the toxic gases including hydrogen sulfide, ammonia, CH4 and combustible gases shall be carried out and confirmation shall be given that they are below the safety limits.

7.1.5 The operator shall know the characteristics of the chemicals and/or agents used and be familiar with emergency measures and preventive measures.

Secondary pollution control 7.2

The bioreactor for deodorization produces waste leachate containing residual nutrients 7.2.1 and microbial metabolic products and detached biofilm. For a bioreactor treating odour gas with a high hydrogen sulfide concentration, the waste leachate can be very acidic. The waste leachate can be discharged into the influent before the WWTP and treated with the original wastewater. National regulations regarding indirect discharge, especially pH range, should be taken into account.

7.2.2 Bioaerosol exists in treated gas and is emitted after biological treatment. Usually there is no need to do extra disinfection on the treated gas unless there is evidence that high risk pathogens exist.

7.2.3 Waste packing media removed from the bioreactor shall firstly be dried and then sent to some solid waste disposal site (composting for instance) after verifying that it does not pose a health risk.

Bibliography

- WANI A.H., BRANION R.M.R., LAU A.K. Biofiltration: A promising and cost-effective cortrol technology for odours, VOCs and air toxics. Journal of Environmental Science and Forth Part A. 1997, 32 pp. 2027–2055 PARMAR G.R., & RAO N.N. Emerging control technologies for volatile oganic compounds. Crit. Rev. Environ. Sci. Technol. 2009, 39 (1) pp. 41–78 [1]
- [2]
- IRANPOUR R., Cox H.H.J., DESHUSSES M.A., SCHROEPIRG, Z.D. Literature review of air pollution control biofilters and biotrickling filters for orbot and volatile organic compound removal. Environ. Prog. 2005, **24** (3) pp. 254–261 [3]
- Noz R. Odourassessmentand management in wastewater Nev. Environ. Sci. Technol. 2011, **41** (10) pp. 915–950 LEBRERO R., BOUCHY L., STUETA R., [4] treatment plants: A review Cr
- ASTM D 1391, Standard Method for Measurement of Odor in Atmospheres (Dilution Method) [5]
- EN 13725, Air quality Determination of odour concentration by dynamic olfactometry [6]
- [7] GB/T 14675-93, Air quality-Determination of odour-Triangle odour bag method
- [8] NFPA 820, Standard for Fire Protection in Wastewater Treatment and Collection Facilities
- [9] T/CAEPI 29-2020 Technical requirements for the equipment of waste gas biopurification
- DOBSLAW D. 2020) Challenges in biological and non-biological waste air treatment. Habilitation [10] Thesis. University of Stuttgart. http://dx.doi.org/10.18419/opus-10906

https://www.china-gauges.com/

British Standards Institution (BSI)

BSI is the national body responsible for preparing British Standards and other standards-related publications, information and services. BSI is incorporated by Royal Charter. British Standards and other standardization products are published by BSI Standards Limited.

The knowledge embodied in our standards has been carefully assembled in a dependable format and refined through our open consultation process. Organizations of all sizes and across all sectors choose standards to help them achieve their goals

Information on standards

We can provide you with the knowledge that your organization needs to succeed. Find out more about British Standards by visiting our website at bsigroup.com/standards or contacting our Customer Services team or Knowledge Centre.

Buying standards

You can buy and download PDF versions of BSI publications, including British and adopted European and international standards, through our website at bsigroup. com/shop, where hard copies can also be purchased.

If you need international and foreign standards from other Standards Development Organizations, hard copies can be ordered from our Customer Services team.

Copyright in BSI publications

All the content in BSI publications, including British Standards, is the property of and copyrighted by BSI or some person or entity that owns copyright in the information used (such as the international standardization bodies) and has formally licensed such information to BSI for commercial publication and use.

Save for the provisions below, you may not transfer, share or disseminate any portion of the standard to any other person. You may not adapt, distribute, commercially exploit or publicly display the standard or any portion thereof in any manner whatsoever without BSI's prior written consent.

Storing and using standards

Standards purchased in soft copy format:

- A British Standard purchased in soft copy format is licensed to a sole named user for personal or internal company use only.
- The standard may be stored on more than one device provided that it is accessible by the sole named user only and that only one copy is accessed at any one time.
- · A single paper copy may be printed for personal or internal company use only.

Standards purchased in hard copy format:

- A British Standard purchased in hard copy format is for personal or internal company use only.
- It may not be further reproduced in any format to create an additional copy. This includes scanning of the document

If you need more than one copy of the document, or if you wish to share the document on an internal network, you can save money by choosing a subscription product (see 'Subscriptions').

Subscriptions

Our range of subscription services are designed to make using standards easier for you. For further information on our subscription products go to bsigroup. com/subscriptions

With British Standards Online (BSOL) you'll have instant access to over 55,000 British and adopted European and international standards from your desktop. It's available 24/7 and is refreshed daily so you'll always be up to date.

You can keep in touch with standards developments and receive substantial discounts on the purchase price of standards, both in single copy and subscription format, by becoming a BSI Subscribing Member.

PLUS is an updating service exclusive to BSI Subscribing Members. You will automatically receive the latest hard copy of your standards when they're revised or replaced

To find out more about becoming a BSI Subscribing Member and the benefits of membership, please visit bsigroup.com/shop

With a Multi-User Network Licence (MUNL) you are able to host standards publications on your intranet. Licences can cover as few or as many users as you wish. With updates supplied as soon as they're available, you can be sure your documentation is current. For further information, email cservices@bsigroup.com.

Revisions

Our British Standards and other publications are updated by amendment or revision. We continually improve the quality of our products and services to benefit your business. If you find an inaccuracy or ambiguity within a British Standard or other BSI publication please inform the Knowledge Centre.

Useful Contacts

Customer Services Tel: +44 345 086 9001 Email: cservices@bsigroup.com

Subscriptions Tel: +44 345 086 9001

Email: subscriptions@bsigroup.com

Knowledge Centre Tel: +44 20 8996 7004

Email: knowledgecentre@bsigroup.com

Copyright & Licensing

Tel: +44 20 8996 7070 Email: copyright@bsigroup.com

BSI Group Headquarters

389 Chiswick High Road London W4 4AL UK

